

VOX CLEARTONE SYSTEM


TRANSMITTER

- 1 - insert microphone
- 2 - switch unit on
- 3 - select channel



RECEIVER

- 1 - insert earphone
- 2 - switch unit on
- 3 - select channel
- 4 - adjust volume



Note:

- Always make sure the transmitter and receivers are on the same channel
- Do not use more than one transmitter per channel

RECEIVER



*Warning

*Any changes or modifications to this receiver, not expressly approved by the party responsible for compliance, could void the user's authority to operate the equipment
*This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation"