



- 1 - Power Button** - Press to Turn On/Hold to Turn Off
- 2 - Volume** - Press to Turn Volume Up or Down
- 3 - Channel** - Press to Change Channel Up or Down
- 4 - Audio Port** - Guest Headphone Insert/Guide Microphone Insert

TECHNICAL SUPPORT

vox@voxnetworkusa.com - **Email**

480-659-1074 - **Call**

480-747-1092 - **Text**

* Guides can mute the transmitter by turning the volume down to the lowest setting

VDR Micro - Guest



VDR Transmitter - Guide

